



User / Installation Manual

0

A: Remove the left, right panels and front panel
 B: Installation of the power supply (PSU)
 C: Installation of fan(s) and/or radiator(s)
 D: Installation of fan(s) and/or radiator(s)
 E: Installation of the Motherboard
 F: Installation of 3.5"HDD and 2.5"SSD
 G: Installing PCI/PCI-e card(s) and removing the expansion slot covers
 H: Connecting and controlling of the Two Fans

Accessory bag

1	X4	2	X3	3	X14
4	X4				

A

• Remove the left, right panels and front panel

C

• Install rear fans

B

• Install power supply

D

• Install front panel fans. Front panel fans can be mounted on the outside, inside, or stuck to the front panel
 • Install top fans

E

• Install the Motherboard
 • Install your board by ensuring the copper mounting points are situated in the correct position for your Motherboard and secure with mounting screws (No.3)
 Please Note: Additional copper mounting points are provided if required. Room to fit ATX & Micro-ATX Motherboard

F

• Install 3.5"HDD and 2.5"SSD
 • Product can be installed with one SSD and one HDD or two HDD

2.5"SSD
 3.5"HDD

G

• Installing a video card
 • Remove the rear protective iron plate, install the graphics card in the correct position, and lock it

H

• Connect corresponding lines